



Certified



Manufactured in Australia

HomeGuard®

Precision Termite Management

HomeGuard® Service Penetrations

- Slip the collar over the penetration pipe and push down to a depth where it will be fully integrated within the concrete pour.
- Do not glue the collars to the pipes.
- Install prior to pouring of the concrete slab.
- Secure one “cable tie” around the collar to attached firmly to the penetration.
- HomeGuard® warning tape should be attached above the HomeGuard® FlexiCollar.
- HomeGuard® FlexiCollars are available in 40, 50, 80, and 100 mm.



Cable Tie



821028

Please always refer to the HomeGuard® Installation Manual for further information