

Protectacote

HomeGuard® Protectacote and Primer provide total termite protection for awkward places.

HomeGuard® Protectacote is a high impact, acrylic polymer latex, and termiticidal paint product which contains Bifenthrin. It is approved in accordance with AS 3660.1 and AS 3660.3 – Termite Management. The purpose of HomeGuard Protectacote paint is to deter termites from gaining concealed access so as to provide whole of building protection.

Primer

- A ready to use solution.
- HomeGuard® Protectacote Primer must be applied on all applications prior to the first coat of HomeGuard® Protectacote, especially to older or contaminated, porous and friable surfaces that have been cleaned.
- Application is by brush, roller or spray gun and has a coverage rate of 10 M²/L, and at normal ambient conditions is touch dry in 10-15 minutes.
- Shake well before use.
- Is available in a 5 L container.



Protectacote

- A ready to use product, do NOT add water.
- Can be applied by roller, brush or heavy-duty airless spray gun at a rate of 1.5 litres per square metre. Applications are for use on masonry, concrete and fibre board.
- HomeGuard® Protectacote Primer must be applied first.
- Multiple coats of product can be applied depending on the situation and thickness requirements. Additionally, thickness and reinforcing can be increased by incorporating non-woven fibreglass cloth for joints and corners.
- Has a shelf life of one year when stored in a dry place between 10 and 23°C.
- When fluid it can be cleaned with water. After curing, it can be removed by mineral turpentine, toluol or lacquer thinners.
- Upon completion of application, it should be left to cure for at least one day before tiling or backfilling.
- Supplied in 15 litre/22 kg pails.

Non Construction Joint

STEP 1		ALWAYS prepare surface and apply HomeGuard® Protectacote Primer
STEP 2		Apply HomeGuard® Protectacote Termite and Waterproof Barrier
STEP 3		Apply 2 nd & 3 rd coat of HomeGuard® Protectacote Termite and Waterproof Barrier

Construction Joint

STEP 1		ALWAYS prepare surface and apply HomeGuard® Protectacote Primer
STEP 2		Apply HomeGuard® Protectacote Termite and Waterproof Barrier
STEP 3		Install non-woven fibreglass cloth
STEP 4		Apply 2 nd & 3 rd coat of HomeGuard® Protectacote Termite and Waterproof Barrier

Please always refer to the HomeGuard® Installation Manual for further information